## APPENDIX D

## WEIGHTS AND MEASURES


For site inventory or reconnaissance, this section describes quick-and-dirty methods for estimating the physical size of AML sites when in the field with nothing more than the equipment listed in Appendix A. Estimate length with paces and convert to feet or yards as described under Distance in Appendix C. The following methods provide crude estimates of area, volume, and tonnages. These methods are adequate only for preliminary planning, cost estimates, and budgeting. Afterwards, if the site warrants detailed characterization and engineering, revise estimates with professional land surveys.

## AREA

Match the given area with one of the shapes below. Pace the indicated sides and convert into length with preceding unit pace length. Substitute lengths into given formula and calculate area. For a complex area, subdivide into simple shapes given below, calculate area for each shape, and add areas for a total area.


Square:

Area =  $a^2$  or Area = 0.5  $d^2$ 




Rectangle:

Area = ab




Parallelogram (opposite sides parallel):

Area = ah




Trapezoid (four sides, two parallel):

Area = 0.5h(a+b) or Area = hm




Triangle:

Area = 0.5bh




Circle:

Area =  $3.14r^2$  or Area =  $0.785d^2$ Circumference = 6.28r or = 3.14d



Alternative Method For Irregular Shapes

Area =  $h[.05(y_0+y_1)+y_1+y_2+y_3+y_{n-1}]$ 




## VOLUME


Match the given volume with one of the shapes below. Pace the indicated sides and convert into length with above unit pace length. Where a formula requires a base area, calculate area with formulas in preceding section. Substitute lengths and base areas into given formula and calculate volume. For a complex volume, subdivide into simple shapes given below, calculate volume for each shape, and add volumes for a total volume.

In the following formulas B is area of base, and h is altitude of the volume. Altitude can be obtained from topographic maps by subtracting contour elevation of the base from contour elevation of the top. Alternatively, pace the side slope, measure its vertical angle with clinometer, and use trigonometry to determine the altitude.

Prism or Cylinder:


Volume = Bh where B is area of base.






Pyramid or Cone:


Volume = 0.33Bh where B is area of base.






Frustum of Pyramid or Cone:


Volume =  $0.33[A_1+A_2+(A_1A_2)^{0.5}]h$ where  $A_1$  and  $A_2$  are areas of bases.





Wedge:

Volume =  $0.5Bh((L_1+L_2+L_3)/3)$ where B is area of base.



TONNAGE

Select appropriate unit weight from Table D-I. Substitute unit weight and volume in the following formula and calculate tonnage.

Tonnage =  $\_$  yd<sup>3</sup> x  $\_$  tons/yd<sup>3</sup>

WEI	TABLE D-I	*
Material	Loose	Bank**
114001141	tons/cu yd	tons/cu yd
Basalt	1.65	2.50
Bauxite, Kaolin	1.20	1.60
Caliche	1.05	1.90
Carnotite, Uranium Ore	1.38	1.85
Cinders Clay-Natural Bed	0.48 1.40	0.73 1.70
Dry	1.25	1.55
Wet	1.40	1.75
Clay & Gravel-Dry	1.20	1.40
Wet	1.30	1.55
Coal-Anthracite, Raw	1.00	1.35
Washed	0.93	
Ash, Bituminous Coal	0.45-0.55	0.50-0.75
Bituminous, Raw	0.80	1.08
Decomposed Rock-	0.70	
75% Rock, 25% Earth	1.65	2.35
50% Rock, 50% Earth	1.45	1.93
25% Rock, 75% Earth	1.33	1.65
Earth-Dry Packed	1.33	1.60
Wet Excavated	1.35	1.70
Loam	1.05	1.30
Granite-Broken	1.40	2.30
Gravel-Pitrun Dry	1.63 1.28	1.83
Dry, 1/4-2 in.	1.43	1.60
Wet, 1/4-2 in.	1.70	1.90
Gypsum-Broken	1.53	2.68
Crushed	1.35	2.35
Hematite, Iron Ore	2.00-2.70	2.35-3.20
Limestone-Broken	1.30	2.20
Crushed	1.30	2.75
Magnetite, Iron Ore Pyrite, Iron Ore	2.35 2.18	2.75
Sand-Dry, Loose	1.20	2.55
Damp	1.43	1.60
Wet	1.55	1.75
Sand & Clay-Loose	1.35	1.70
Compacted	2.03	
Sand & Gravel-Dry	1.45	1.63
Sandstone	1.70	1.88
Sandstone Shale	1.28 1.05	2.13 1.40
Slag-Broken	1.48	2.48
Snow-Dry	0.11	-
Wet	0.43	-
Stone-Crushed	1.35	2.25
Taconite, Iron Ore	1.80-2.10	2.60-3.05
Top Soil	0.80	1.15
Tap Rock	1.48	2.20
"Varies with moisture, grain siz determine exact material weights	e, compaction, e	tc. rertorm tests to
*Bank: quantity of an excavati	on measured in n	lace before being disturbed
REF: Caterpillar Performance Ha	ndbook, Peoria II	L, Oct. 1989, ed. 20, p. 888.
	,	-,, ca. Lo, p. 000.